

SWIMMING POOL HEAT PUMP UNIT

Installation & Instruction Manual



CONTENTS

1. Preface	1
2. Specifications	4
2.1 Performance Data of Swimming Pool Heat Pump Unit	4
2.2 Dimensions for Swimming Pool Heat Pump Unit	8
3. Installation and Connection	10
3.1 Installation illustration	10
3.2 Swimming Pool Heat Pumps Location	11
3.3 How Close to Your Pool?	11
3.4 Swimming Pool Heat Pumps Plumbing	12
3.5 Swimming Pool Heat Pumps Electrical Wiring	13
3.6 Initial Start-up of the Unit	13
4. Use and Operation <u>Instruction</u>	14
4.1 Interface display	14
4.2 Key and icon function instruction	14
4.3 Startup & shutdown	16
4.4 Mode switch	16
4.5 Temperature setting	17
4.6 Clock setting	18
4.7 Silent setting	20
4.8 Keyboard lock	21
4.9 Fault interface	21
4.10 Parameter list and breakdown table	22
4.11 Interface drawin	24
4.12 Main board	26

5. Maintenance and Inspection	29
6 .Appendix	34
6 . 1 Cable specification	34
6.2 Comparison table of refrigerant saturation temperature	35

1. PREFACE

- In order to provide our customers with quality, reliability and versatility, this product has been made to strict production standards. This manual includes all the necessary information about installation, debugging, discharging and maintenance. Please read this manual carefully before you open or maintain the unit. The manufacture of this product will not be held responsible if someone is injured or the unit is damaged, as a result of improper installation, debugging, or unnecessary maintenance. It is vital that the instructions within this manual are adhered to at all times. The unit must be installed by qualified personnel.
- The unit can only be repaired by qualified installer centre, personnel or an authorised dealer.
- Maintenance and operation must be carried out according to the recommended time and frequency, as stated in this manual.
- Use genuine standard spare parts only.
Failure to comply with these recommendations will invalidate the warranty.
- Swimming Pool Heat Pump Unit heats the swimming pool water and keeps the temperature constant. For split type unit, The indoor unit can be Discretely hidden or semi-hidden to suit a luxury house.

Our heat pump has following characteristics:

1 Durable

The heat exchanger is made of PVC & Titanium tube which can withstand prolonged exposure to swimming pool water.

2 Installation flexibility

The unit can be installed outdoors.

3 Quiet operation

The unit comprises an efficient rotary/ scroll compressor and a low-noise fan, which guarantees its quiet operation.

4 Advanced controlling

The unit includes micro-computer controlling, allowing all operations to be set. Operation status can be displayed on the LCD wire controller. Remote controller can be chosen as future option.



● WARNING

1. PREFACE

Do not use means to accelerate the defrosting process or to clean ,

Other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames , an operating gas appliance or an operating electric heater.)

Do not pierce or burn .

Be aware that refrigerants may not contain an odour,

Appliance shall be installed ,operated and stored in a room with a floor area larger than 30m²

NOTE The manufacturer may provide other suitable examples or may provide additional information about the refrigerant odour.

1. PREFACE

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance shall be installed in accordance with national wiring regulations.
- Do not operate your air conditioner in a wet room such as a bathroom or laundry room.
- Before obtaining access to terminals, all supply circuits must be disconnected.
- An all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device (RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.)
- Do not pierce or burn
- Appliance shall be installed, operated and stored in a room with a floor area larger than 30 m²

Be aware that refrigerants may not contain an odour.

The installation of pipe-work shall be kept to a minimum 30 m²

Spaces where refrigerant pipes shall be compliance with national gas regulations. Servicing shall be performed only as recommended by the manufacturer.

- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

All working procedure that affects safety means shall only be carried by competent persons.

Transport of equipment containing flammable refrigerants

Compliance with the transport regulations

Marking of equipment using signs

Compliance with local regulations

Disposal of equipment using flammable refrigerants

Compliance with national regulations

1. PREFACE

Storage of equipment/appliances

The storage of equipment should be in accordance with the manufacturer's instructions .

Storage of packed (unsold) equipment

Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge .

The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations .

1. PREFACE

Caution & Warning

1. The unit can only be repaired by qualified installer centre personnel or an authorised dealer. (for Europe market)
2. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. (for Europe market)

Children should be supervised to ensure that they do not play with the appliance.
3. Please make sure that the unit and power connection have good earthing, otherwise may cause electrical shock.
4. If the supply cord is damaged, it must be replaced by the manufacturer or our service agent or similarly qualified person in order to avoid a hazard.
5. Directive 2002/96/ EC (WEEE) :

The symbol depicting a crossed-out waste bin that is underneath the appliance indicates that this product, at the end of its useful life, must be handled separately from domestic waste, must be taken to a recycling centre for electric and electronic devices or handed back to the dealer when purchasing an equivalent appliance.
6. Directive 2002/95/ EC (RoHs) : This product is compliant with directive 2002/95/ EC (RoHs) concerning restrictions for the use of harmful substances in electric and electronic devices.
7. The unit CANNOT be installed near the flammable gas. Once there is any leakage of the gas, fire can be occur.
8. Make sure that there is circuit breaker for the unit, lack of circuit breaker can lead to electrical shock or fire.
9. The heat pump located inside the unit is equipped with an over-load protection system. It does not allow for the unit to start for at least 3 minutes from a previous stoppage.
10. The unit can only be repaired by the qualified personnel of an installer center or an authorized dealer. (for North America market)
11. Installation must be performed in accordance with the NEC/CEC by authorized person only. (for North America market)
12. USE SUPPLY WIRES SUITABLE FOR 75°C.
13. Caution: Single wall heat exchanger, not suitable for potable water connection.

2 . SPECIFICATION

2.1 Performance data of Swimming Pool Heat Pump Unit

*** REFRIGERANT : R32

Hydro-Pro Inverter	MOD EL	PX7/32	PX11/32	PX14/32
Part nr.		7028283	7028284	7028285
Heating capacity A27/W27 (max.-min.)	kW	7.24-1.82	11-2.23	14-2.52
Heating capacity A15/W25 (max.-min.)	kW	5.64-1.39	7.9-1.58	9.5-1.79
Power input (max.-min.)	kW	1.8-0.13	2.05-0.15	2.15-0.16
Swimming pool volume*	m ²	20-35	30-55	40-70
Rated current	A	7.9	9.0	9.5
Minimum fuse	A	10	12	12
C.O.P. at A27/W27		13.13-5.66	13.24-5.84	13.35-6.64
C.O.P. at A15/W25		7.15-4.41	7.22-4.67	7.28-4.52
Power supply	V/Ph/ Hz	220~240/1/ 50	220~240/1/ 50	220~240/1/ 50
Heat exchanger		Twist-titanium tube in PVC		
Compressor brand		Mitsubishi	Mitsubishi	Mitsubishi
Refrigerant		R32	R32	R32
Fan quantity		1	1	1
Fan direction		Horizontal	Horizontal	Horizontal
Fan speed	RP M	400-700	400-800	400-800
Power input of Fan	W	40	40	40
Noise level(1m)	dB (A)	38-50	39-51	42-53
Noise level(10m)	dB (A)	19-29	20-30	22-32
Water connection	m m	50	50	50

2 .SPECIFICATION

Nominal flow rate	m ³ / h	2.4	3.0	4.9
R32 Volume	kg	0.35	0.43	0.48
CO2 equivalent	To n	0.24	0.29	0.32
Wifi moudule		include	include	include
Net dimension	m m	1000×418×6 05	1000×418× 605	1000×418× 605

H*provided it is correctly insulated , calculation model : min vol 4x heating capacity (A15/W25)
max vol 7x heating capacity (A15/W25)

2 . SPECIFICATION

2 . 1 Performance data of Swimming Pool Heat Pump Unit

*** REFRIGERANT : R32

Hydro-Pro Inverter	MODEL	PX17/32	PX21/32
Part nr.		7028286	7028287
Heating capacity A27/W27 (max.-min .)	kW	16-3.25	19-3.5
Heating capacity A15/W25 (max.-min .)	kW	12.6-2.55	14-2.55
Power input (max.-min.)	kW	3.7-0.22	3.8-0.25
Swimming pool volume*	m ²	45-80	55-95
Rated current	A	16.0	17.5
Minimum fuse	A	20	25
C.O.P. at A27/W27		13.64-6.45	13.22-6.21
C.O.P. at A15/W25		7.22-4.61	7.21-4.62
Power supply	V/Ph/Hz	220~240/ 1/ 50	220~240/ 1/ 50
Heat exchanger		Twist-titanium tube in PVC	
Compressor brand		Mitsubishi	Mitsubishi
Refrigerant		R32	R32
Fan quantity		1	1
Fan direction		Horizontal	Horizontal
Fan speed	RP M	300-750	400-750
Power input of Fan	W	75	75
Noise level(1m)	dB (A)	42-54	42-55
Noise level(10m)	dB (A)	24-33	24-33
Water connection	m m	50	50

2 .SPECIFICATION

Nominal flow rate	m ³ / h	5.2	6.0
R32 Volume	kg	0.6	0.67
CO2 equivalent	Ton	0.41	0.45
Wifi moudule		include	include
Net dimension	m m	1046×435×767	1160×470×862

H* provided it is correctly insulated , calculation model : min vol 4x heating capacity (A15/W25)
max vol 7x heating capacity (A15/W25)

2.SPECIFICATION

2.1 Performance data of Swimming Pool Heat Pump Unit

*** REFRIGERANT : R32

Hydro-Pro Inverter	MODEL	PX25/32	PX25T/32
Part nr.		7028288	7028289
Heating capacity A27/W27 (max.-min.)	kW	25.5-5.7	25.5-5.7
Heating capacity A15/W25 (max.-min.)	kW	18.6-4.68	18.6-4.68
Power input (max.-min.)	kW	5.24-0.35	6.78-0.35
Swimming pool volume*	m ²	75-130	75-130
Rated current	A	23.00	10.61
Minimum fuse	A	30	15
C.O.P. at A27/W27		13.32-6.18	13.32-6.18
C.O.P. at A15/W25		7.24-4.65	7.24-4.65
Power supply	V/Ph/Hz	220~240/ 1/ 50	380/3/ 50
Heat exchanger		Twist-titanium tube in PVC	
Compressor brand		Mitsubishi	Mitsubishi
Refrigerant		R32	R32
Fan quantity		2	2
Fan direction		Horizontal	Horizontal
Fan speed	RP M	400-800	400-800
Power input of Fan	W	75*2	75*2
Noise level(1m)	dB (A)	42-57	42-57
Noise level(10m)	dB (A)	26-37	26-37
Water connection	m m	50	50

2 .SPECIFICATION

Nominal flow rate	m ³ / h	8.6	8.5
R32 Volume	kg	1.2	1.2
CO2 equivalent	Ton	0.81	0.81
Wifi moudule		include	include
Net dimension	m m	1165×470×127 5	1165×470×127 5

H* provided it is correctly insulated , calculation model : min vol 4x heating capacity (A15/W25)
max vol 7x heating capacity (A15/W25)

2.SPECIFICATION

2.1 Performance data of Swimming Pool Heat Pump Unit

*** REFRIGERANT : R32

Hydro-Pro Inverter	MODEL	PX30/32	PX30T/32
Part nr.		7028290	7028291
Heating capacity A27/W27 (max.-min.)	kW	30-6.7	30-6.7
Heating capacity A15/W25 (max.-min.)	kW	23.7-5.46	23.7-5.46
Power input (max.-min.)	kW	7.22-0.42	7.35-0.42
Swimming pool volume*	m ²	100-175	100-175
Rated current	A	30.00	12.50
Minimum fuse	A	40	20
C.O.P. at A27/W27		13.46-6.28	13.46-6.28
C.O.P. at A15/W25		7.28-4.65	7.28-4.65
Power supply	V/Ph/Hz	220~240/ 1/ 50	380/3/ 50
Heat exchanger		Twist-titanium tube in PVC	
Compressor brand		Mitsubishi	Mitsubishi
Refrigerant		R32	R32
Fan quantity		2	2
Fan direction		Horizontal	Horizontal
Fan speed	RP M	400-900	400-900
Power input of Fan	W	75*2	75*2
Noise level(1m)	dB (A)	42-58	42-58
Noise level(10m)	dB (A)	28-38	28-38
Water connection	m m	50	50

2 .SPECIFICATION

Nominal flow rate	m ³ / h	10.0	10.0
R32 Volume	kg	1.5	1.5
CO2 equivalent	Ton	1.01	1.01
Wifi moudule		include	include
Net dimension	m m	1165×470×127 5	1165×470×127 5






H* provided it is correctly insulated , calculation model : min vol 4x heating capacity (A15/W25)
max vol 7x heating capacity (A15/W25)

2.SPECIFICATION



2.2 The dimensions for Swimming Pool Heat Pump Unit

Model:PX7/32


unit: mm



unit: mm



2.SPECIFICATION



615




2 .SPECIFICATION

2.2 The dimensions for Swimming Pool Heat Pump Unit

Model:PX21/32

1160

unit: mm




unit: mm

1161

Water outlet


Φ50

2 .SPECIFICATION



3 . INSTALLATION AND CONNECTION

3. 1 Installation illustration



Installation items:

The factory only provides the main unit and the water unit; the other items in the illustration are necessary spare parts for the water system ,that provided by users or the installer.

Attention:

Please follow these steps when using for the first time

- 1 .Open valve and charge water.
- 2 . Make sure that the pump and the water-in pipe have been filled with water.
- 3 .Close the valve and start the unit.

ATTN: It is necessary that the water-in pipe is higher than the pool surface .

The schematic diagram is for reference only. Please check the water inlet/outlet label on the heat pump while plumbing installation .

The schematic diagram is for reference only. Please check the water inlet/outlet label on the heat pump while plumbing installation .

3 . INSTALLATION AND CONNECTION

The controller is mounted on the wall

3. INSTALLATION AND CONNECTION

3.2 Swimming Pool Heat Pumps Location


The unit will perform well in any outdoor location provided that the following three factors are presented:

- 1. Fresh Air - 2. Electricity - 3. Pool filter piping

The unit may be installed virtually anywhere outdoors. For indoor pools please consult the supplier. Unlike a gas heater, it has no draft or pilot light problem in a windy area.

DO NOT place the unit in an enclosed area with a limited air volume, where the units discharge air will be re-circulated.

DO NOT place the unit to shrubs which can block air inlet. These locations deny the unit of a continuous source of fresh air which reduces its efficiency and may prevent adequate heat delivery.



3.3 How Close To Your Pool?

Normally, the pool heat pump is installed within 7.5 metres of the pool. The longer the

3. INSTALLATION AND CONNECTION

distance from the pool, the greater the heat loss from the piping. For the most part ,the piping is buried. Therefore, the heat loss is minimal for runs of up to15 meters(15 meters to and from the pump = 30 meters total) , unless the ground is wet or the water table is high . A very rough estimate of heat loss per 30 meters is 0 .6 kW-hour,(2000BTU) for every 5 °C difference in

temperature between the pool water and the ground surrounding the pipe , which translates to about 3% to 5% increase in run time .

3. INSTALLATION AND CONNECTION


3.4 Swimming Pool Heat Pumps Plumbing

The Swimming Pool Heat Pumps exclusive rated flow titanium heat exchanger requires no special plumbing arrangements except bypass(please set the flow rate according to the nameplate) . The water pressure drop is less than 10kPa at max. Flow rate . Since there is no residual heat or flame Temperatures , The unit does not need copper heat sink piping. PVC pipe can be run straight into the unit.

Location: Connect the unit in the pool pump discharge (return) line downstream of all filter and pool pumps , and upstream of any chlorinators , ozonators or chemical pumps .

Standard model have slip glue fittings which accept 32mm or 50 mm PVC pipe for connection to the pool or spa filtration piping. By using a 50 NB to 40NB you can plumb 40NB

Give serious consideration to adding a quick coupler fitting at the unit inlet and outlet to allow easy draining of unit for winterizing and to provide easier access should servicing be required.



➡ To pool

PVC COUPLER

RECOMMENDED(Provided)



← From pump

CONDENSATION

DRAIN

BARB FTG

Condensation: Since the Heat pump cools down the air about 4 -5°C, water may condense on the fins of the horseshoe shaped evaporator. If the relative humidity is very high , this could be as much as several litres an hour. The water will run down the fins into the basepan and drain out through the barbed plastic condensation drain fitting on the side of the basepan .

3 . INSTALLATION AND CONNECTION

This fitting is designed to accept 20mm clear vinyl tubing which can be pushed on by hand and run to a suitable drain. It is easy to mistake the condensation for a water leak inside the unit.

NB: A quick way to verify that the water is condensation is to shut off the unit and keep the pool pump running. If the water stops running out of the basepan , it is condensation . AN

EVEN QUICKER WAY IS to TEST THE DRAIN WATER FOR CHLORINE - if the is no chlorine present , then it's condensation .

3. INSTALLATION AND CONNECTION

3.5 Swimming Pool Heat Pumps Electrical Wiring

NOTE: Although the unit heat exchanger is electrically isolated from the rest of the unit , it simply prevents the flow of electricity to or from the pool water. Grounding the unit is still required to protect you against short circuits inside the unit. Bonding is also required.

The unit has a separate molded-in junction box with a standard electrical conduit nipple already in place. Just remove the screws and the front panel , feed your supply lines in through the conduit nipple and wire-nut the electric supply wires to the three connections already in the junction box (four connections if three phase) . To complete electrical hookup , connect Heat Pump by electrical conduit , UF cable or other suitable means as specified (as permitted by local electrical authorities) to a dedicated AC power supply branch circuit equipped with the proper circuit breaker, disconnect or time delay fuse protection .

Disconnect - A disconnect means (circuit breaker , fused or un-fused switch) should be located within sight of and readily accessible from the unit , This is common practice on commercial and residential air conditioners and heat pumps. It prevents remotely-energizing unattended equipment and permits turning off power at the unit while the unit is being serviced.

3.6 Initial startup of the Unit

NOTE- In order for the unit to heat the pool or spa, the filter pump must be running to circulate water through the heat exchanger.

Start up Procedure - After installation is completed , you should follow these steps:

1. Turn on your filter pump. Check for water leaks and verify flow to and from the pool .
2. Turn on the electrical power supply to the unit , then press the key ON/OFF of wire controller, It should start in several seconds .
3. After running a few minutes make sure the air leaving the top(side) of the unit is cooler(Between 5- 10 °C)
4. With the unit operating turn the filter pump off. The unit should also turn off automatically,
5. Allow the unit and pool pump to run 24 hours per day until desired pool water temperature is reached. When the water-in temperature reaches this setting, the unit will slow down for a period of time , if the temperature is maintained for 45 minutes the unit will turn off. The unit will now automatically restart (as long as your pool pump is running)when the pool temperature drops more than 0.2 below set temperature .

Time Delay- The unit is equipped with a 3 minute built-in solid state restart delay included to protect control circuit components and to eliminate restart cycling and contactor chatter.

3 . INSTALLATION AND CONNECTION

This time delay will automatically restart the unit approximately 3 minutes after each control circuit interruption. Even a brief power interruption will activate the solid state 3 minute restart delay and prevent the unit from starting until the 5 minute countdown is completed.

4. Use and Operation Instruction

4.1 General presentation

The heat pump is equipped with a digital control panel with a touch screen, electronically connected and pre-set at the factory in heating mode.



Legend

1	Water Outlet temperature
1	On/Off/Back
2	
1	Main screen
3	
1	Setpoint temperature
4	
1	System time

4. Use and Operation Instruction

1	Auto mode
2	Cooling mode
3	Heating mode
4	Compressor's ON indicator
5	Fan
6	Timer
7	Defrost mode
8	Alarm
9	Lock screen
1 0	Water Input temperature

4. Use and Operation Instruction

2 1	Access Advanced Settings
2 2	Access list of faults
2 3	Set data and time
2 4	Confirm
2 5	Back (changes not confirmed)

OFF mode

When the heat pump is idle (in standby mode), OFF is displayed as shown on the screen.

The black screen indicates that the heat pump is idle; settings can be adjusted in this mode.




ON mode

When
or pr
scre



4. Use and Operation Instruction

To switch from OFF to ON mode and vice versa, press the  button.

4. Use and Operation Instruction

4.2 Timer function settings

The date and time can be set either in ON or in OFF mode.



4. Use and Operation Instruction



- Press 1 times on to return to the main screen.

4. Use and Operation Instruction

4.3 Setting the On/Off timers

Setting this function is necessary if you would like to run the heat pump for a shorter period than what is defined by the filtration clock. Therefore, you can program a deferred start and an anticipated stop or simply stop a certain timeframe from running (at night, for example).

It is possible to set one Start Timer and one Stop Timer.

The setting step is "hour to hour".






4. Use and Operation Instruction



Blue highlighting = Activated

4. Use and Operation Instruction

Grey = Deactivated

- Press 2 times on  to return to the main screen.

4. Use and Operation Instruction

4.4 Adjust setpoint

The setpoint can be changed either in ON or in OFF mode with an accuracy of 0.5°C.






4. Use and Operation Instruction



4. Use and Operation Instruction


- Press 1 times on  to return to the main screen.

It is recommended to never exceed 30°C to avoid alteration of the liners.

4.5 Modeselection



4. Use and Operation Instruction

- Press 1 times on  to return to the main screen.

4. Use and Operation Instruction

4.6 Locking and unlocking the touch screen

The screen can be locked or unlocked either in ON or in OFF mode.



Lock activated



Lock deactivated

4.7 SILENT function settings

Silence mode enables the heat pump to be used in economic and very silent mode when the heating needs are low (maintaining the pool temperature or need for ultra-silent operation).

This function can be Activated/Deactivated manually or using a Timer.


Activation/Deactivation





Silent mode activated

4

- Press 1 times on  to return to the main screen.


4. Use and Operation Instruction

Adjusting the SILENT mode Timer





4 .OPERATION AND USE

- Press 2 times on  to return to the main screen.


The setting step is "hour to hour".

Once the Timer is activated, it is active 7 days a week.

4.8 Troubleshooting guide



Certain operations must be carried out by an authorized technician.

If a fault occurs on the heat pump  appears in the top left-hand corner of the screen.

Refer to following table



Error codes





Description

Date and time
of appearance

4. Use and Operation Instruction

When the problem is resolved, the error is automatically acknowledged and the triangle disappears.

- To delete the error list, press on .
- Press 2 times on  to return to the main screen.

4. Use and Operation Instruction

4.9 Parameter list and breakdown table

4.9.1 Electronic control fault table

Can be judged according to the remote controller failure code and troubleshooting

Protect/fault	Failure display	Reason	Elimination methods
Inlet Temp. Sensor Fault	P01	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Outlet Temp. Sensor Fault	P02	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Amibent Temp. Sensor Fault	P04	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Coil 1 Temp. Sensor Fault	P05	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Coil 2 Temp. Sensor Fault	P15	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Suction Temp. Sensor Fault	P07	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Discharge Temp. Sensor Fault	P081	The temp. Sensor is broken or short circuit	Check or change the temp. Sensor
Exhaust Air over Temp Prot.	P082	The compressor is overload	Check whether the system of the compressor running normally
Antifreeze Temp. Sensor Fault	P09	Antifreeze temp. sensor is broken or short circuited	Check and replace this temp. sensor
Pressure sensor Fault	PP	The pressure Sensor is broken	Check or change the pressure Sensor or pressure
High Pressure Prot.	E01	The high-pressure switch is broken	Check the pressure switch and cold circuit
Low Pressure Prot.	E02	Low pressure1 protection	Check the pressure switch and cold circuit

Flow Switch Prot.	E 0 3	No water/little water in water system	Check the pipe water flow and water pump
Waterway Anti-freezing Prot.	E 0 5	Water temp. or ambient temp. is too low	Check the water temp. and ambient temp.
Inlet and outlet temp. too big	E 0 6	Water flow is not enough and low differential pressure	Check the pipe water flow and whether water system is jammed or not
Anti-freezing Prot.	E 0 7	Water flow is not enough	Check the pipe water flow and whether water system is jammed or not
Primary Anti-freezing Prot.	E 1 9	The ambient temp. is low	Check the ambient temp. sensor
Secondary Anti-freezing Prot.	E 2 9	The ambient temp. is low	Check the ambient temp. sensor
Comp. Overcurrent Prot.	E 0 5 1	The compressor is overload	Check whether the system of the compressor running normally
Communication Fault	E 0 8	Communication failure between wire controller and mainboard	Check the wire connection between remote wire controller and mainboard
Communication Fault (speed control module)	E 0 8 1	Speed control module and main board communication fail	Check the communication connection
Low AT Protection	T P	Ambient temp. is too low	Check the ambient temp. sensor
EC fan feedback Fault	F 0 5 1	There is something wrong with fan motor and fan motor stops running	Check whether fan motor is broken or locked or not
Fan Motor1 Fault	F 0 3 1	1. Motor is in locked-rotor state 2.The wire connection between DC-fan motor module and fan motor is in bad contact	1.Change a new fan motor 2.Check the wire connection and make sure they are in good contact

4. Use and Operation Instruction

Fan Motor2 Fault	F032	1. Motor is in locked-rotor state 2.The wire connection between DC-fan motor module and fan motor is in bad contact	1.Change a new fan motor 2.Check the wire connection and make sure they are in good contact
------------------	------	---	--

Frequency conversion board fault table:

Protection/fault	Fault display	Reason	Elimination methods
Drv1 MOP alarm	F001	MOP drive alarm	Recovery after the 150s
Inverter offline	F002	Frequency conversion board and main board communication failure	Check the communication connection
IPM protection	F003	IPM modular protection	Recovery after the 150s
Comp. Driver Failure	F004	Lack of phase, step or drive hardware damage	Check the measuring voltage check frequency conversion board hardware
DC Fan Fault	F005	Motor current feedback open circuit or short circuit	Check whether current return wires connected motor
IPM Overcurrent	F006	IPM Input current is large	Check and adjust the current measurement
Inv. DC Overvoltage	F007	DC bus voltage > Dc bus over-voltage protection value	Check the input voltage measurement
Inv. DC Lessvoltage	F008	DC bus voltage < Dc bus over-voltage protection value	Check the input voltage measurement
Inv. Input Lessvolt.	F009	The input voltage is low, causing the input current is high	Check the input voltage measurement
Inv. Input Overvolt.	F100	The input voltage is too high, more than outage protection current RMS	Check the input voltage measurement
Inv. Sampling Volt.	F101	The input voltage sampling fault	Check and adjust the current measurement
Comm. Err DSP-PFC	F102	DSP and PFC connect fault	Check the communication connection

Input Over Cur.	F 2 6	The equipment load is too large	Check whether the unit is overloaded
PFC fault	F 2 7	The PFC circuit protection	Check the PFC switch tube short circuit or not
IPM Overheating	F 1 5	The IPM module is overheat	Check and adjust the current measurement
Weak Magnetic Warn	F 1 6	Compressor magnetic force is not enough	Restart the unit after multiple power failures, if the fault still exists, replace the compressor
Inv. Input Out Phase	F 1 7	The input voltage lost phase	Check and measure the voltage adjustment
IPM Sampling Cur.	F 1 8	IPM sampling electricity is fault	Check and adjust the current measurement
Inv. Temp. Probe Fail	F 1 9	Sensor is short circuit or open circuit	Inspect and replace the sensor
Inverter Overheating	F 2 0	The transducer is overheat	Check and adjust the current measurement
Inv. Overheating Warn	F 2 2	Transducer temperature is too high	Check and adjust the current measurement
Comp. Over Cur. Warn	F 2 3	Compressor electricity is large	The compressor over-current protection
Input Over Cur. Warn	F 2 4	Input current is too large	Check and adjust the current measurement
EEPROM Error Warn	F 2 5	MCU error	Check whether the chip is damaged Replace the chip
V15V over/undervoltage fault	F 2 8	The V15V is overload or undervoltage	Check the V15V input voltage in 13.5v~16.5v or not range

4. Use and Operation Instruction


4.9.2 Parameter list

Meaning	Default	Remarks
Refrigeration target temperature set point	27℃	Adjustable
Heating the target temperature set point	27℃	Adjustable
Automatic target temperature set point	27℃	Adjustable

4.10 Interface drawin


Sign	Meaning
V	12V (power +)
R	No use
T	No use

4.10.1 Wire control interface diagram and definition



4.10.2 Controller interface diagram and definition

4. Use and Operation Instruction



4 . Use and Operation Instruction

Main board of the input and output interface instructions below

Number	Sign	Meaning
01	R01	Compressor (output220-230VAC)
02	R02	Water pump (output 220-230VAC)
03	R03	4-way valve (output 220-230VAC)
04	R04	High speed offan (output220-230VAC)
05	R05	Low speed offan (output 220-230VAC)
06	L	Live wire (input 220-230VAC)
07	N	Neutral wire (input 220-230VAC)
08	AI/DI01	Emergency switch (input)
09	AI/DI02	Water flow switch (input)
10	AI/DI03	System low pressure (input)
11	AI/DI04	System high pressure (input)
12	AI/DI05	System suction temperature (input)
13	AI/DI06	Water input temperature (input)
14	AI/DI07	Water output temperature (input)
15	AI/DI08	System fan coil temperature (input)
16	AI/DI09	Ambient temperature (input)
17	AI/DI10	Mode switch (input)
18	AI/DI11	Master-slave machine switch / Antifreeze temperature (input)
19	AI12(50K)	System Exhaust temperature (input)
20	0_5V_IN	Compressor current detection/Pressure sensor(input)
21	PWM_IN	Master-slave machine switch / Feedback signal of EC fan (input)
22	PWM_OUT	AC fan control (output)

4 . Use and Operation Instruction

23	0 10V_OUT	EC fan control (output)
24	+5V	+5V (output)
25	+12V	+12V (output)
26	GND	Frequency conversion board communications
27	485_B1	
28	485_A1	
29	12V	
30	GND	Color line controller communication
31	485_B2	
32	485_A2	
33	12V	
34	CN9	Electronic expansion valve
35	GND	The port for centralized control
36	485_B3	
37	485_A3	
38	12V	
39	CN12	Program download interface

5. MAINTENANCE AND INSPECTION

- Check the water supply device and the release often . You should avoid the condition of no water or air entering into system , as this will influence unit's performance and reliability.

You should clear the pool/spa filter regularly to avoid damage to the unit as a result of the dirty or clogged filter.

- The area around the unit should be dry, clean and well ventilated. Clean the side heating exchanger regularly to maintain good heat exchange as conserve energy .
- The operation pressure of the refrigerant system should only be serviced by a certified technician .
- Check the power supply and cable connection often , .Should the unit begin to operate abnormally, switch it off and contact the qualified technician .
- Discharge all water in the water pump and water system ,so that freezing of the water in the pump or water system does not occur. You should discharge the water at the bottom of water pump if the unit will not be used for an extended period of time . You should check the unit thoroughly and fill the system with water fully before using it for the first time after a prolonged period of no usage .
- Checks to the area

Prior to beginning work on systems containing flammable refrigerants , safety checks are necessary to ensure that the risk of ignition is minimised. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system .

- Work procedure

Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

- General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material .

- Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work , to ensure the technician is aware of potentially flammable atmospheres. Ensure that the

leak detection equipment being used is suitable for use with flammable refrigerants , i.e. non-sparking , adequately sealed or intrinsically safe .

- Presence of fire extinguisher

5. MAINTENANCE AND INSPECTION

If any hot work is to be conducted on the refrigeration equipment or any associated parts , appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area .

5. MAINTENANCE AND INSPECTION

● No ignition sources

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion . All possible

ignition sources , including cigarette smoking , should be kept sufficiently far away from the site of installation , repairing , removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space. Prior to work taking place , the area

around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks . “No Smoking” signs shall be displayed.

● Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work . A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere .

● Checks to the refrigeration equipment

Where electrical components are being changed , they shall be fit for the purpose and to the correct specification . At all times the manufacturer's maintenance and service guidelines

shall be followed. If in doubt consult the manufacturer's technical department for assistance .

The following checks shall be applied to installations using flammable refrigerants:

The charge size is in accordance with the room size within which the refrigerant containing parts are installed ;

The ventilation machinery and outlets are operating adequately and are not obstructed ;
If an indirect refrigerating circuit is being used , the secondary circuit shall be checked for the presence of refrigerant ;

Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected ;

Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components , unless the components are constructed of materials which are inherently resistant to being

corroded or are suitably protected against being so corroded.

● Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with . If the fault cannot be corrected immediately but it is necessary to continue operation, an

adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

5. MAINTENANCE AND INSPECTION

Initial safety checks shall include:

- . That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- . That there no live electrical components and wiring are exposed while charging , recovering or purging the system;
- . That there is continuity of earth bonding.

5. MAINTENANCE AND INSPECTION

● Repairs to sealed components

1) During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it

is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

2) Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

● Ensure that apparatus is mounted securely.

Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

● Repair to intrinsically safe components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

● Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

● Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

● Leak detection methods

The following leak detection methods are deemed acceptable for systems containing flammable refrigerants.

Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated

5. MAINTENANCE AND INSPECTION

in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work .

If a leak is suspected , all naked flames shall be removed/ extinguished.

If a leakage of refrigerant is found which requires brazing , all of the refrigerant shall be recovered from the system , or isolated (by means of shut off valves) in a part of the system remote from the leak. Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process .

5. MAINTENANCE AND INSPECTION

● Removal and evacuation

When breaking into the refrigerant circuit to make repairs or for any other purpose conventional procedures shall be used. However, it is important that best practice is

followed since flammability is a consideration. The following procedure shall be adhered to:

- . Remove refrigerant;
- . Purge the circuit with inert gas;
- . Evacuate;
- . Purge again with inert gas;
- . Open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders. The system shall be "flushed" with OFN to render the unit safe. This process may need to be repeated several times. Compressed air or oxygen shall not be used for this task.

Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system.

When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing

operations on the pipe-work are to take place.

Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available. working on them.

● Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

● Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding

the total system charge is available. All cylinders to be used are designated for the

recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of

5. MAINTENANCE AND INSPECTION

flammable refrigerants . In addition , a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine , check that it is in satisfactory

working order, has been properly maintained and that any associated electrical

components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct

recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders .

If compressors or compressor oils are to be removed , ensure that they have been

evacuated to an acceptable level to make certain that flammable refrigerant does not

remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be

employed to accelerate this process. When oil is drained from a system , it shall be carried out safely.

5. MAINTENANCE AND INSPECTION

● Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

a) Become familiar with the equipment and its operation .

b) Isolate system electrically.

c) Before attempting the procedure ensure that :

- . Mechanical handling equipment is available , if required , for handling refrigerant cylinders;
- . All personal protective equipment is available and being used correctly;

- . The recovery process is supervised at all times by a competent person;
- . Recovery equipment and cylinders conform to the appropriate standards .

d) Pump down refrigerant system , if possible .

e) If a vacuum is not possible , make a manifold so that refrigerant can be removed from various parts of the system .

f) Make sure that cylinder is situated on the scales before recovery takes place .

g) Start the recovery machine and operate in accordance with manufacturer's instructions .

h) Do not overfill cylinders. (No more than 80 % volume liquid charge) .

i) Do not exceed the maximum working pressure of the cylinder, even temporarily.

j) When the cylinders have been filled correctly and the process completed , make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.

k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

● Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them .

- Cylinders shall be kept upright.

- Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.

- Label the system when charging is complete (if not already) .

- Extreme care shall be taken not to overfill the refrigeration system .

5 . MAINTENANCE AND INSPECTION

Prior to recharging the system it shall be pressure tested with OFN . The system shall be

leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site .

- The safety wire model is 5*20_5A/250VAC ,And must meet the explosion-proof requirements

6.APPENDIX

6.1 Cable specification

(1) Single phase unit

Nameplate maximum current	Phase line	Earth line	MC B	Creepage protector	Signal line
No more than 10A	2×1.5mm ²	1.5mm ²	20A	30mA less than 0.1 sec	n×0.5mm ²
10~16A	2×2.5mm ²	2.5mm ²	32A	30mA less than 0.1 sec	
16~25A	2×4mm ²	4mm ²	40A	30mA less than 0.1 sec	
25~32A	2×6mm ²	6mm ²	40A	30mA less than 0.1 sec	
32~40A	2×10mm ²	10mm ²	63A	30mA less than 0.1 sec	
40~63A	2×16mm ²	16mm ²	80A	30mA less than 0.1 sec	
63~75A	2×25mm ²	25mm ²	100A	30mA less than 0.1 sec	
75~101A	2×25mm ²	25mm ²	125A	30mA less than 0.1 sec	
101~123A	2×35mm ²	35mm ²	160A	30mA less than 0.1 sec	
123~148A	2×50mm ²	50mm ²	225A	30mA less than 0.1 sec	
148~186A	2×70mm ²	70mm ²	250A	30mA less than 0.1 sec	
186~224A	2×95mm ²	95mm ²	280A	30mA less than 0.1 sec	

(2) Three phase unit

6.APPENDIX

Nameplate maximum current	Phase line	Earth line	MC B	Creepage protector	Signal line
No more than 10A	$3 \times 1.5\text{mm}^2$	1.5mm^2	20A	30mA less than 0.1 sec	$n \times 0.5\text{mm}^2$
10~16A	$3 \times 2.5\text{mm}^2$	2.5mm^2	32A	30mA less than 0.1 sec	
16~25A	$3 \times 4\text{mm}^2$	4mm^2	40A	30mA less than 0.1 sec	
25~32A	$3 \times 6\text{mm}^2$	6mm^2	40A	30mA less than 0.1 sec	
32~40A	$3 \times 10\text{mm}^2$	10mm^2	63A	30mA less than 0.1 sec	
40~63A	$3 \times 16\text{mm}^2$	16mm^2	80A	30mA less than 0.1 sec	
63~75A	$3 \times 25\text{mm}^2$	25mm^2	100A	30mA less than 0.1 sec	
75~101A	$3 \times 25\text{mm}^2$	25mm^2	125A	30mA less than 0.1 sec	
101~123A	$3 \times 35\text{mm}^2$	35mm^2	160A	30mA less than 0.1 sec	
123~148A	$3 \times 50\text{mm}^2$	50mm^2	225A	30mA less than 0.1 sec	
148~186A	$3 \times 70\text{mm}^2$	70mm^2	250A	30mA less than 0.1 sec	
186~224A	$3 \times 95\text{mm}^2$	95mm^2	280A	30mA less than 0.1 sec	

When the unit will be installed at outdoor, please use the cable which can against UV.

6.APPENDIX

6.2 Comparison table of refrigerant saturation temperature

Pressure (MPa)	0	0.3	0.5	0.8	1	1.3	1.5	1.8	2	2.3
Temperature (R410A)(τ)	-51.3	-20	-9	4	11	19	24	31	35	39
Temperature (R32)(τ)	-52.5	-20	-9	3.5	10	18	23	29.5	33.3	38.7
Pressure (MPa)	2.5	2.8	3	3.3	3.5	3.8	4	4.5	5	5.5
Temperature (R410A)(τ)	43	47	51	55	57	61	64	70	74	80
Temperature (R32)(τ)	42	46.5	49.5	53.5	56	60	62	67.5	72.5	77.4

Note: _____



Note: _____





Code:83900215