

## Application of SabaPVC 2810

#### **Attention**

If you are working with solvent-based products, please ensure for sufficient ventilation and avoid fire and sparks.

### 1. Preparation







- cut off the pipe at a right angle, bevel (15°) and deburr
- · mark the push-in depth of the pipe
- clean with Sabaclean PVC & ABS until surface tarnishes
- · remove any moisture with clean paper or a non-fluffy cloth

#### 2. Adhesive application





- · apply adhesive evenly to pipe and fitting
- · apply thin layer of adhesive around the inside of the fitting
- · apply thick layer lengthwise along the pipe
- · avoid excess adhesive residue in the pipe

## 3. Mounting and finishing







- immediately connect pipe to the fitting, in a straight way and without turning, then hold together for a few seconds
- remove excess adhesive immediately
- do not move the bonded pipes for 5 minutes after bonding, or for 15 minutes in temperatures below 10 °C.
   Pipes with a diameter larger than 63 mm should not be moved for 30 minutes.

SABA Dinxperlo BV

Industriestraat 3 NL7091 DC Dinxperlo PO Box 3 NL7090 AA Dinxperlo T +31(0)315 65 89 99 F +31(0)315 65 32 07 E info@saba.nl www.saba.nl

Our recommendations and instructions for use are based on the current state of know-how and technique. Clients and users must evaluate our products themselves in terms of their desired application and requirements. We are not liable if our products are used without due consideration of our recommendations and/or operating instructions.

Furthermore, SABA' Dinxperlo BV's General Terms and Conditions apply to our recommendations and instructions for use and to the supply of our products.



# Application of SabaPVC 2810

Prevent heavy mechanical stress like moving the pipes or closing the trench within 10-12 hours. Before putting pressure on the construction, please consider the adhesive's drying time (see table below):

diameter	nm) (°C)	drying time		
(mm)		0 bar / no pressure (hours)	bar <10 (hours)	bar 10-15 (hours)
16 - 63	> 15	-	2	4
	5 - 15	-	4	8
75 - 90	> 15	-	4	8
	5 - 15	-	8	16
16 - 160	> 15	1	-	-
	5-15	2	-	-

#### **General** issues

- · follow the pipe and fitting instructions from the supplier
- · blow pipes that will not immediately be used through or fill with water
- · do not dilute SABA PVC adhesives
- · do not use any thickened adhesive
- · remove spilled adhesive or cleaner immediately
- · close cans immediately after use
- · wind will reduce the open time

## Coverage per bond and brush advice\*

pipe diameter (mm)	push in length (mm)	SabaPVC 2810 (connections per litre)	brush type (cm)
16	14	2000	round 0,75
20	16	1500	round 0,75
25	19	1000	flat 2,50
32	22	700	flat 2,50
40	26	500	flat 2,50
50	31	300	flat 2,50
63	38	240	flat 5,00
75	44	190	flat 5,00
90	51	150	flat 5,00
110	61	100	flat 5,00
125	69	60	flat 5,00
140	76	50	flat 5,00
160	86	40	flat 6,00

<sup>\*</sup>These values are based on average quantities used in practice. In reality, the quantity is dependent on the specific conditions as the kind of application, the viscosity of the adhesive, diametrical clearance and temperature.

## **Safety recommendations**

For additional safety information please refer to the relevant SABA safety information sheet.

SABA Dinxperlo BV

Industriestraat 3 NL7091 DC Dinxperlo PO Box 3 NL7090 AA Dinxperlo T +31(0)315 65 89 99 F +31(0)315 65 32 07 E info@saba.nl www.saba.nl

Our recommendations and instructions for use are based on the current state of know-how and technique. Clients and users must evaluate our products themselves in terms of their desired application and requirements. We are not liable if our products are used without due consideration of our recommendations and/or operating instructions. Furthermore, SABA' Dinxperlo BV's General Terms and Conditions apply to our recommendations and instructions for use and to the supply of our products.